

CAD-ARCHIVO:		
Denominación.	CIATESA ISM 80-95-120-155	



**NO SE PUEDE ANULAR EL MANDO DE LA MAQUINA.  
PONER EN CALOR Y MAXIMA T° EN INVIERNO Y EN FRIO Y MINIMA T° EN VERANO UNA VEZ HAYA ENCENDIDO DICHO TERMOSTATO.**

**NO SE PUEDE ANULAR EL MANDO DE LA MAQUINA.  
PONER EN CALOR Y MAXIMA T° EN INVIERNO Y EN FRIO Y MINIMA T° EN VERANO UNA VEZ HAYA ENCENDIDO DICHO TERMOSTATO.**

CONTACTO NORMALMENTE  
ABIERTO LIBRE DE POTENCIAL


CARGA MAXIMA POR  
RELE  
 $220V \approx 1A \cos \varphi > 0,9$

The diagram illustrates the relay assembly. It includes a main relay body with a large rectangular contact area. A terminal block is attached to the side, featuring three terminals labeled N, L, and T. A mounting bracket is shown attached to the bottom of the relay body. The terminal block is connected to a power source, indicated by a line labeled 220V.

CONTACTO NORMALMENTE  
ABIERTO LIBRE DE POTENCIAL

CARGA MAXIMA POR  
RELE  
 $220V \approx 1A \cos \varphi > 0,9$

The diagram illustrates the relay assembly. It includes a main relay body with a large rectangular contact area. A terminal block is attached to the side, featuring three terminals labeled N, L, and T. A mounting bracket is shown attached to the bottom of the relay body. The terminal block is connected to a power source, indicated by a line labeled 220V.



CONECTOR  
J4